

TMAX Digital Inc. warrants this product against defects in material or workmanship for a period of one (1) year from the date of original purchase ("Limited Warranty period") and at its own option either to (a) repair your product with new or refurbished parts, or (b) replace it with a new or a refurbished product. TMAX Digital Inc. will incur no liability whatsoever to provide packaging for warranty items. Upon receipt of the warranty item, should it be determined that the packaging is insufficient, TMAX Digital Inc may at its discretion, void the warranty. The consumer is responsible for the transportation cost to TMAX Digital Inc. A nominal handling fee does apply. You must receive a return authorization number before sending a unit in for service.

TO OBTAIN WARRANTY SERVICE

Should it be necessary to contact Customer Support, call (800) 890-1288 or email at cs@nuvision.com. You will be instructed on how your claim will be processed. Have pertinent information available including proof of purchase and an understanding of the issue.

You must retain the original bill of sale to provide proof of purchase. Call or email Customer Support to assess the problem. No service or shipment will be accepted unless an RMA # is provided to you and attached or printed to the shipping carton along with a copy of the bill of sale.

This warranty is effective only if the product was purchased through an Authorized Retail Seller and the unit is operated in North America. You are responsible for all tariffs and taxes imposed to ship or receive warranty or replacement units to and from the U.S. Warranty extends only to defects in materials or workmanship and does not extend to any other products that have been lost, discarded or damaged by misuse, accident, neglect, acts of God, such as lightning, improper installation, improper maintenance or modification. The Limited Warranty ALSO DOES NOT COVER damages from having been previously altered, modified, repaired or serviced by anyone other than the service facilities authorized by TMAX Digital Inc. to render such services. Warranty does not cover cosmetic damage or lost accessories.

TMAX DIGITAL Inc. reserves the rights to change the warranty from time to time without written notice to you.

DISCLAIMER OF WARRANTY

EXCEPT FOR THE FOREGOING WARRANTIES, TMAX DIGITAL INC. HEREBY DISCLAIMS AND EXCLUDES ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO ANY AND/OR ALL IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND/OR ANY WARRANTY WITH REGARDS TO ANY CLAIMS OF INFRINGEMENT.

LIMITATION OF LIABILITY

BOTH YOURS AND TMAX'S LIABILITY SHALL BE LIMITED TO THE PRICE PAID FOR PRODUCT. IN NO EVENT SHALL TMAX DIGITAL INC. BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY KIND INCLUDING, BUT NOT LIMITED TO, COMPENSATION, REIMBURSEMENT OR DAMAGES ON ACCOUNT OF THE LOSS OF PRESENT OR PROSPECTIVE PROFITS OR FOR ANY OTHER REASON WHATSOEVER.

Contact NuVision Technical Support
Email: cs@nuvision.com
Phone: (800) 890-1288
Hours: 8:30am to 5:30pm PST M-F

NUVISION


TPEN-H1BK Digital Pen Instructions

This NuVision Digital Pen works with any device using Windows INK with MPP protocol.

PACKAGE CONTENTS:

- Digital Pen
- (1) AAAA Battery
- (2) Soft Tips
- (2) Hard Tips
- Tip Replacement Tool

NOTE: One of the Tips is installed in the Digital Pen.




INSTALL THE BATTERY

1. Unscrew the top of the pen by turning it counter-clockwise.
2. Insert one battery, positive (+) side down, into the battery compartment.
3. Replace the pen top by screwing back on, clockwise.

USING THE DIGITAL PEN

To 'awaken' the pen from sleep mode, press either Eraser or Alt buttons. Your pen will be active and ready to use.

PARTS OF THE PEN




1	Tip
2	Pen Head
3	Eraser Button
4	Alt Button (Mouse Right-Click)
5	Clip
6	Top of Pen
7	AAAA Battery (Inserts Positive end towards the Tip)
8	Use Tip Replacement Tool to remove/replace Tip

RECOMMENDED: Keep the unused tips in the foam portion of the package.

REPLACING THE TIP

The NuVision Digital Pen comes with 2 types of Tips, Soft and Hard. They can be removed and replaced by using the included



Tip Replacement Tool as follows:

1. With the Tip Replacement Tool in one hand, and the Pen in another, bring the Tool over the tip of the Pen.
2. Pinch the tool closed around the Tip, and slowly pull the Tip out of the body of the Pen.
3. To place a new tip, use the Tip Replacement Tool to remove a tip from the packaging. With the pointed end of the Tip pinched in the Tool, slide the new Tip into the Pen until the neck of the Tip is not visible.

WARNING: Choking Hazard
This device may contain small parts which may be a choking hazard to children under 3. Keep small parts away from children.